

## TEC Cart Instructions

AV/Tech Support phone extension 7280



Push "ON" to turn the projector on.

Volume Control

DVD/VCR Controls

### Turning on the Projector

- Push the button under Display marked "ON."

### Adjusting the Volume

- Ensure the projector is on (instructions above).
- Locate the area on the control panel marked "VOLUME" and turn the knob on the right. The lights will indicate the level of sound.

### Using the Computer

- Ensure the projector is on (instructions above).
- Turn on the computer CPU and monitor and log on with the same credentials as your South Central College email.
- Push the button labeled "PC."

### Using the Document Camera

- Ensure the projector is on (instructions above).
- Push the button labeled "DOC CAM."

### Using the DVD/VCR

- Ensure the projector is on (instructions above).
- Push the button labeled "DVD" or "VCR."
- The controls for the players are located to the right of the main controls. You can also use the remote control in the TEC cart.

### Using a Laptop

- Connect the VGA cable on the desk to the laptop.
- Connect the Ethernet cable on the cart to the laptop.
- Connect the power adapter to the laptop.
- Connect audio cable to laptop's headphone jack.
- Ensure the projector is on (instructions above).
- Push the button labeled "LAPTOP."



Hook up these connectors to your laptop. Plug your laptop in for power.

**For immediate assistance dial x7280**

If you'd like to schedule a walk-through,  
email [helpdesk@southcentral.edu](mailto:helpdesk@southcentral.edu)